MITvoip Telephone Ring Tones and No Ring

MITvoip Telephone Ring Tones and No Ring

You can set a separate ring tone for each phone number that is assigned to your phone. This allows you to distinguish by ear which number is ringing. You can also set a ring tone to Silent Ring so that line does not ring audibly on your phone. (You can still answer calls by pressing the line key or the **Answer** soft key.)

Set a Ring Tone or No Ring

Note: Setting a Ring Tone only affects your phone. It will not change how a shared line rings at other phones.

1. Press the **Menu** button.
2. Select **Settings**.
3. Select **Basic**.
4. Select **Ring Type**.
5. If prompted, select the line you want to configure.
   Result: A list of 12 ring tones will appear, the first of which is Silent Ring. A check mark indicates the current ring tone for that line.
6. Use the arrow keys to scroll through the list.
   - To hear a sample of a ring tone, highlight it and press the **Play** soft key.
   - To set a ring tone, highlight it and press the **Select** soft key.
   - To set a line to no ring, select the first tone, **Silent Ring**.