

Printer configuration page for Dell 5110cn

Printer configuration page for Dell 5110cn

Follow these steps to print a configuration page for a Dell 5110cn Printer:

1. Press the **menu** button.
2. Press the **down arrow** until you see Report/List
3. Press the **check** in the middle.
4. Press the **down arrow** until you see Printer Setting
5. Press the **check** in the middle.

For more information on reports and kinds of test pages you can print, see the manual at [Dell](#)