There's a red light blinking on my phone. What does it mean?

Q: There's a red light blinking on my phone. What does it mean?

Answer

That is the Message Waiting Indicator, and it means that you have received new voice mail messages. The light will go off when you check your messages. See Basic Voice Mail Functions for instructions about playing and handling your messages.